

OUTDOOR CCTV CAMERA PRO

INSTALLATION

The camera is supplied with a mounting kit for attaching to a wall. Before you affix the camera in position, please ensure the cable is of adequate length to reach the DVR.

To mount the camera on a wall or ceiling, follow these instructions:

1. Ensure the surface you want to mount the cameras on is solid and can support the weight.
2. Accurately mark on the wall the position of the holes to be drilled.
3. Drill to the correct depth in the wall, as indicated by the plugs.
4. Insert plugs into the drilled holes.
5. Secure the bracket to the wall using the provided screws.

The camera can either be mounted to a wall or a ceiling:



WALL MOUNT POSITION



CEILING MOUNT POSITION

To attach the camera to the bracket:

1. Screw it onto the exposed thread
2. Tighten the bolt to lock it in place.

To adjust the camera's position:

Turn the bolt arms anti-clockwise to release the corresponding point of adjustment, position the camera, then turn the bolt arms clockwise to re-tighten.

